

Angled Brush Assembly

4520-BRASY-23

(includes: brush, instagrip tubing and hose clamps)

Angled Brush
1675-BRANB


Nozzle Kit
4550-NOZKT

Basket for SW-23
1530-BASKT

Valve, Female
1605-FVALV

(Required)
Bushing
1600-BUSHG

False Bottom
for SW-23
1030-FABOT-23



Sink Kit
for SW-23
4465-SFKIT-23
(includes:
quick disconnect
plug and valve)

Quick Release Pin
1535-QRPIN

Mat Support Grid
1410-MSGRID-PL